

# Product Information Sheet

## Cig-Arrête Battery Sounder Beacon (Part No CSA-CSBB)




### Combined Battery Sounder /Beacon

The Cig-Arrête Combined Sounder Beacon provides both a visual and audible indication that an alarm has been generated by the Cig-Arrête System.

The unit is powered via 2 x PP3 alkaline batteries each providing 9V dc (18V dc in total) and is normally used as part of the Cig-Arrête Master/Slave System.

### WIRING DIAGRAM FOR CSA-CSBB BATTERY POWERED SOUNDER BEACON



The installation of the unit is facilitated by removing the link and connecting to the Daughter Board (CSA-DBD) of either a CSA-GDV or CSA-GDT (The Master Unit). The volt free witch will then close the circuit under alarm conditions and energise the Sounder Beacon.

Selector switches on the sounder beacon provide the user with 3 volume levels, 3 different sounder tones, or the option of the flasher unit only.

Testing the unit before installation can be achieved by simply inserting the 2 x PP3 batteries. If the link is in place the sounder beacon will operate in its factory default mode.

