

## To Operate

Switch Power On or Press Re-Set  
Buzzer will Bleep

### Fill



- 1 Place Hose **B** in sample container
- 2 Press Fill Button and release
- 3 At required level press Fill button again

### Re-Set



Unit is now set for repeat filling of the same amount  
Position fill hose in next container and press Fill button  
Buzzer will sound on completion

## To Change Fill amount

Press Re-Set and continue from stage 1

Outlet  
**B**



**Hoyles Electronic Developments Ltd**

T. 01744 886600 F. 01744 886607 E. [sales@hoyles.com](mailto:sales@hoyles.com) W. [www.hoyles.com](http://www.hoyles.com)

Inlet  
**A**